

Sprint Power Vision Smart Device Treo™ 700wx by Palm®



"I wish I could" just became yes you can on the Sprint Power Vision Network!

Differentiators

Features and Design

- Palm's first version of the Treo with the familiar Windows Mobile operating system, that allows users to stay connected to the office with quick and easy one handed access to mobile broadband speeds on Sprint's Power Vision network.

Target Customers

- High end consumers and business users (primarily business users) who need to stay connected to their office will benefit from the broadband-like speeds and prefer the Windows Mobile OS.

Sprint Mobile Broadband with Sprint Power VisionSM

- Where it's available, experience broadband-like speeds over the Sprint Power Vision network when accessing Sprint Power Vision services and content, retrieve customized, up-to-date Web content such as news, sports, and weather, download large attachments, and access corporate data on the spot.

Bluetooth Wireless Technology

- Built-in radio technology for short-range wireless communication. When used with your Sprint PCS phone and accessories (i.e., headset), Bluetooth allows fast, secure transmission without cables or wires, even though the two devices are not in line-of-sight. Bluetooth wireless accessories are sold separately.

Phone as Modem-Capable

- Your Sprint Power Vision phone can be a high-speed internet connection for your laptop computer anywhere on the Sprint Power Vision Network. Simply connect your Power Vision phone using a USB cable.

Note: Phone as Modem Plan is required.

Basics

- Digital dual-band
- Up to 4.5 hours talk time in digital mode
- 240 x 240 display

Services Supported

- Sprint Mobile Broadband with Power VisionSM
- Windows Mobile 5.0
- Microsoft® Office Word, Excel® and PowerPoint® Mobile, Pictsel PDF Viewer
- Internet Explorer Mobile
- Sprint PCS® Voice Command
- Bluetooth 1.2
- On Demand
- GoodLinkTM
- Messaging

Built-in Key Features

- 1.3 megapixel camera with 2x digital zoom and video capture
- SD I/O expansion slot
- MP3 player
- GPS
- QWERTY keyboard
- Phone (modem capable)
- Organizer
- 128 MB of memory (64 MB available user storage)
- TTY
- Voice/Memo recorder
- Internal phonebook
- Speakerphone
- Enhanced attachment viewing and editing
- Productivity tools
- Headset jack

Customizable

- Picture caller ID
- Ringtones and alerts



On Demand

- Set and then receive customized, up-to-date Web content such as sports, weather, news, money, and movie information, on demand—the way you want it.

GoodLink™

- Get GoodLink™—the enterprise-class, software solution for mobile messaging. It provides secure access to real-time e-mail and corporate data with a familiar, Outlook®-like interface.

What's in the Box with the Treo 700wx by Palm?

- Treo 700wx by Palm
- Lithium ion (Li-Ion) battery
- AC travel charger
- USB sync cable
- Stereo headset
- Setting Up E-mail Guide
- Read This First Poster
- Quick Reference Guide Booklet
- Software installation CD

Potential Qualifying Questions and Comments

- **How often do you find yourself wanting to check live news, sports, financial markets, weather, etc.?** With this device, you can have high-speed, customized access to news, sports, financial markets, weather, TV Guide®, movie listings, a store locator and a map.
- **Do you need instant access to corporate and personal e-mail accounts at the touch of a button?** With the Treo 700wx by Palm, you can quickly access your e-mail and stay in touch while on the go!
- **Ever wish you could connect your computer to the Internet without the expense of a connection card?** Now you can! The Treo 700wx by Palm is an EVDO device; so you can use your phone as a modem!

Demonstrating the Phone

Turning Wireless Services On and Off

Press **Start** and select **Settings**.

Select the **Connections** tab, and then select **Wireless Manager**.

Turn your smart device's wireless features on/off. (Select **All** to turn all wireless features on/off.)

Press **OK** to finish.

Demonstrating the Phone (Continued)

Viewing a Web Page

Internet Explorer Mobile provides quick and easy access to Web pages. You can view most sites you use on your computer, including those with security and advanced features, such as JavaScript and frames.

To browse the Web, you must activate Sprint PCS Vision data services. Internet Explorer Mobile supports JavaScript, Secure Sockets Layer (SSL), and cookies, but does not support plug-ins (Flash, Shockwave, etc.) or Java applets.

By default, Internet Explorer Mobile scales Web page content to fit your smart device screen so that you can view most of the information without scrolling left or right.



1. Make sure the phone is on.
2. Press **Start** and select **Internet Explorer**.
3. Highlight the address line, enter the address of the Web page you want to view, and then press **Center**. (If you browse to a secure Web page, the **Lock** icon in the address line appears closed instead of open.)
4. Press **Menu** (right softkey), select **View**, and then select any of the following:
 - **One Column:** Arranges Web pages into one column that is as wide as the screen, so that you don't have to scroll horizontally.
 - **Default:** Maintains a layout similar to what you see on a desktop computer, but it makes items smaller and arranges the content so that you can see most of it without scrolling horizontally.
 - **Desktop:** Keeps the same layout and size as on a desktop computer, which requires both horizontal and vertical scrolling.
 - **Full Screen:** Hides the status and navigation areas and fills the entire screen with the Web page. (To exit full screen mode, press (right Softkey) or (left softkey). You can also tap and hold anywhere on the screen and uncheck Full Screen.)
 - **Show Pictures:** Shows or hides pictures on Web pages. (Hiding pictures speeds up the time it takes to load pages.)
5. Do any of the following:
 - To view the previous page, press **Back** (left softkey) or **Backspace**.
 - To refresh the page with the latest content from the Internet, press **Menu** (right softkey) and select **Refresh**.
 - To scroll through the page in **One Column** view or **Default** view, press **Up** or **Down**.
 - To follow a link to another Web page, press **Up** or **Down** to highlight the link, and then press **Center** to go to the selected page.
 - To adjust the size of the text on Web pages, press **Menu** (right softkey), select **Zoom**, and then select the size you want.
 - To view each item in a list, tap the list with your stylus.
 - In a list, press **Down** or **Left** to cycle between items, and press **Center** to accept the change.
 - In a form, such as a browser search field, press **Center** to interact with the form, and then press **Center** to stop interacting with the form.
 - You can send e-mail from a Web page. E-mail address appear as links on Web pages. After you configure an e-mail application on your smart device, you can select an e-mail link to create a message to that address.
6. Press **OK** to close **Internet Explorer Mobile**.

Demonstrating the Phone (Continued)

Creating and Sending a Text Message

Each text message can hold up to 160 characters. To save time, you can select from predefined My Text phrases, such as "Call me" or "On my way." You can add your own My Text phrases, and if you prefer, you can enter the full message text too.

- Go to your **Today** screen and then press **Messaging** (left softkey).
- Press **Left** until you see **Text Messages** in the title bar.
- Press **New** (left softkey).
- Do one of the following to address the message:
 - If the recipient's name and wireless number are in your **Contacts** list, type the first few letters of the first or last name or simply enter the first initial, followed by a space, and then the last initial to find a name. (You can enter the first few numbers of contact's wireless phone number.)
 - If the recipient's name is in an online address book, press Center, enter the name, press Menu (right softkey), and then select **Find Online**. (Select the name, and then select to use either the phone number or e-mail address. For more information, see the Treo 700wx User Guide.)
 - If the recipient's name and wireless number are not in your Contacts list, enter the full wireless number or e-mail address. To address a message to multiple recipients, separate the address with a semicolon (;). (If you address a single text message to three people, you are billed for three messages.)
 - Enter your message, or press **Menu** (right softkey), select **My Text**, and then select a predefined phrase you want to insert.
 - (Optional) Press **Menu** (right softkey) and select Spell Check.
 - (Optional) Press **Menu** (right softkey) and select Message Options.
 - Enter a callback number and then press **OK**.
 - Press **Send** (left softkey).



Employee Proficiency Chart

Use the following chart to track employee proficiency with this device.

Sales Representative Name:	Sprint PCS Phone Checklist	
Treo™ 700wx by Palm®	Verbally Answer and Demonstrate*	Date Completed
Questions	X	09/10/06
Which Sprint services does this device support?		
What key features are built in?		
What are the customizable options?		
What differentiates this device from other devices?		
Can you use this device as a modem?		
* How do you turn Wireless Services on and off?		
* How do you view a Web page?		
What qualifying questions would apply to this device? (The qualifying questions listed are not a complete list.)		
Manager Signoff (Insert Initials)		

Additional Information

Internal:

For "how-to" and troubleshooting information, look up the device in:

- **i-Learn**
For device guides, go to offering number **7299** in i-Learn.
<http://myue.corp.sprint.com/SabaWeb>
- **s.n.c./i.n.c. (Training Section)**
For device guides, log into s.n.c. or i.n.c., then go to **training>Device Sales Guides**.
<http://www.nextel.com/en/support/guides/index.shtml?audience=INDIVIDUAL&language=EN>
- **KMS**
Open Internet Explorer, and then access the **Retail Operations** home page. Click **KMS** from **QUICK LINKS** on the left, and then search by the device name.
- **Customer Equipment (CE)**
For user guides, accessory information, and device or product application troubleshooting, visit the home page on i-Connect:
<http://intranet.sprintspectrum.com/c2k/invoke.cfm?id=2AAC7188-BF3E-11D5-95EE0002B35EBD49>.

External:

- Visit <http://www.sprint.com> for more information on Sprint phones and services.
- Visit www.palm.com for more information on the TreoSM 700wx by Palm®.